



96 x 96

SPECIFICATIONS

DISPLAY

Liquid crystal display with backlight
4 lines, 4 digits per line to show electrical parameters
5th line, 8 digits to show energy
Bar graph for current indication

LCD INDICATIONS

- Integration of energy
- Unit is in configuration menu
- Communication in progress
- MAX DMD** - Maximum and Minimum Demand Power

WIRING INPUT

3 Ø - 4 wire, 3 Ø - 3 wire, 2 Ø - 3 wire and
1 Ø - 2 wire system

RATED INPUT VOLTAGE

11 to 300V AC (L-N);
19 to 519V AC (L-L); Installation Category III (600V)

UL Approval :

11 to 277V AC (L-N);
19 to 480V AC (L-L); Installation Category III (600V)

FREQUENCY RANGE

45-65 Hz

RATED INPUT CURRENT

Nominal 5A AC (Min-11mA, Max-6A)

BURDEN

0.5 VA@5A per phase

CT PRIMARY

1A / 5A to 10,000A (Programmable for any Value)
Note : 1A to 10,000A if CT secondary is 1 else
CT primary is 5A to 10,000A

CT SECONDARY

1A or 5A (programmable)

PT PRIMARY

100V to 500kV (Programmable for any value)

PT SECONDARY

100 to 500V AC (L-L)(Programmable for any value)

Display update time

1 sec. for all parameters

Display Scrolling

Automatic or Manual (Programmable)

POWER CONSUMPTION

MFM384 / MFM384-C / MFM384-230V /
MFM384-C-230V : Less than 8VA
MFM384-24V / MFM384-C-24V : Less than 2VA

ENVIRONMENTAL CONDITIONS

- Indoor use
- Altitude of up to 2000 meters
- Pollution degree II

Temperature : Operating : -10°C to 55°C

Storage : -20°C to 75°C

Humidity : Up to 85% non-condensing

PROTECTION CLASS : II

MOUNTING : Panel mounting

WEIGHT : MFM384 / MFM384-C : 318gms

MFM384-230V / MFM384-C-230V : 362gms

MFM384-24V / MFM384-C-24V : 327gms

OUTPUT

Pulse Output : Voltage range : External 24V DC max.

Current capacity : 100mA max

Pulse Width : 100 ms ± 5ms.

| ORDER CODE INFORMATION | | | |
|------------------------------------|--|---------------|-----------|
| Product | Supply | Certification | |
| | | CE | UL LISTED |
| MFM384 / MFM384-C | 100 to 240V AC, -15% +12%, 50 / 60Hz, (±5%) | — | — |
| MFM384-230V / MFM384-C-230V | 230V AC, ±20%, 50 / 60Hz | — | — |
| MFM384-24V / MFM384-C-24V | DC : 18 to 42V ; AC : 18 to 28V, 50 / 60Hz | — | — |
| MFM384-CE / MFM384-C-CE | 100 to 240V AC, -15% +12%, 50 / 60Hz, (±5%) | ■ | — |
| MFM384-CU / MFM384-C-CU | 100 to 240V AC, -15% +12%, 50 / 60Hz, (±5%) | ■ | ■ |

Installation Category II

| SERIAL COMMUNICATION | |
|--|---|
| [Applicable for MFM384-C / MFM384-C-230V / MFM384-C-24V] | |
| Interface standard and protocol | RS485 and MODBUS RTU |
| Communication address | 1 to 255 |
| Transmission mode | Half duplex |
| Data types | Float and Integer |
| Transmission distance | 500m maximum |
| Transmission Speed | 300, 600,1200, 2400, 4800, 9600,19200 (in bps) |
| Parity | None, Odd, Even |
| Stop bits | 1 or 2 |
| Response time | 100 ms (max and independent of baud rate) |

| ACCURACY : | |
|--------------------------|--|
| Measurement | Accuracy |
| Voltage V _{L-N} | ±0.5% of Full scale |
| Voltage V _{L-L} | ±0.5% of Full scale |
| Current | ±0.5% of Full scale |
| Frequency | ±0.1% For L-N Voltage >20V, For L-L Voltage >35V |
| Active Power | 1% |
| Apparent power | 1% |
| Reactive Power | 1% |
| Power factor | ±0.01 |
| Active energy | Class 1 |
| Reactive energy | Class 1 |
| Apparent energy | Class 1 |
| MAX / MIN Active Power | 1% |
| MAX / MIN Reactive Power | 1% |
| MAX Apparent Power | 1% |

| RESOLUTION : | | | |
|---------------------|--------------------|-------|--|
| PT Ratio x CT Ratio | kWh / kVAh / kVArh | Pulse | |
| <15 | 0.01K | 0.01K | |
| <150 | 0.1K | 0.1K | |
| <1500 | 1K | 1K | |
| <15000 | 0.01M | 0.01M | |
| <150000 | 0.1M | 0.1M | |
| ≥1500000 | 1M | 1M | |

- NOTE :** 1) For Voltage, Current and Power, resolution is automatically adjusted.
2) For power factor, resolution is 0.001
3) blinks after every 5 sec., if load is connected on any one of 3 phases.

SAFETY PRECAUTIONS

- All safety related codifications, symbols and instructions that appear in this operating manual or on the equipment must be strictly followed to ensure the safety of the operating personnel as well as the instrument.
If the equipment is not used in a manner specified by the manufacturer it might impair the protection provided by the equipment.
- Do not use the equipment if there is any mechanical damage.
 - Ensure that the equipment is supplied with correct voltage.

- CAUTION :**
1. Read complete instructions prior to installation and operation of the unit.
 2. Risk of electric shock.
 3. The equipment in its installed state must not come in close proximity to any heating sources, oils, steam, caustic vapors or other unwanted process by products.

WIRING GUIDELINES


- WARNING :**
1. To prevent the risk of electric shock, power supply to the equipment must be kept OFF while doing the wiring arrangement.
 2. Wiring shall be done strictly according to the terminal layout. Confirm that all connections are correct.
 3. Use lugged terminals.
 4. To reduce electromagnetic interference use of wires with adequate ratings and twists of the same in equal size shall be made with shortest connections.
 5. Layout of connecting cables shall be away from any internal EMI source.
 6. Cable used for connection to power source, must have a cross section of 0.5mm² to 2.5mm² (20 to 14AWG; 75°C (min)). These wires shall have current carrying capacity of 6A.
 7. Copper cable should be used (Stranded or Single core cable).
 8. Before attempting work on device, ensure absence of voltages using appropriate voltage detection device.

INSTALLATION GUIDELINES

- CAUTION :**
1. This equipment, being built-in-type, normally becomes a part of main control panel and in such case the terminals do not remain accessible to the end user after installation and internal wiring.
 2. Conductors must not come in contact with the internal circuitry of the equipment or else it may lead to a safety hazard that may in turn endanger life or cause electrical shock to the operator.
 3. Circuit breaker or mains switch must be installed between power source and supply terminals to facilitate power 'ON' or 'OFF' function. However this switch or breaker must be installed in a convenient position normally accessible to the operator.
 4. Before disconnecting the secondary of the external current transformer from the equipment, make sure that the current transformer is short circuited to avoid risk of electrical shock and injury.
 5. The equipment shall not be installed in environmental conditions other than those mentioned in this manual.
 6. The equipment does not have a built-in-type fuse. Installation of external fuse of rating 275V AC / 0.5Amp for electrical circuitry / battery is highly recommended.

MECHANICAL INSTALLATION


- For installing the meter
1. Prepare the panel cutout with proper dimensions as shown below.
 2. Push the meter into the panel cutout. Secure the meter in its place by fitting the clamp on the rear side. Fit clamps on both sides in diagonally opposite location for optimum fitting.
 3. For proper sealing, tighten the screws evenly with required torque.
- Terminal screw tightening torque :
0.68 N-m to 0.79 N-m (6.018 In-Lb to 6.992 In-Lb)
Screw clamp tightening torque : 0.1N-m (0.885 Lb-inch)




MAINTENANCE

1. The equipment should be cleaned regularly to avoid blockage of ventilating parts.
2. Clean the equipment with a clean dry or damp cloth. Do not use any cleaning agent other than water.

TERMINAL CONNECTIONS



FRONT PANEL DESCRIPTION



ONLINE PAGE DESCRIPTION

There are 6 dedicated keys labelled as V, I, VAF, PF, P, E. Use these 6 keys to read meter parameters. Simply press these keys to read the parameters.

| KEY PRESS | ONLINE PAGE DESCRIPTION |
|-------------|---|
| Press "V" | <p>The first screen : Displays line to neutral Voltage of three phase and average line to neutral voltage.</p> <p>The second screen : Displays line to line voltage of three phase and average line to line voltage.</p> <p>The third screen : Displays total percentage harmonics of line to neutral voltage of three phase and average line to neutral voltage.</p> <p>The fourth screen : Displays total percentage harmonics of line to line voltage of three phase and average line to line voltage.</p> <p>The fifth screen : Press for 3 sec, Displays phase sequence indication.</p> <p>Note : 1) For 3 Ø 3 wire system, for only the second and fourth screen will be available. 2) In 1 Ø 2 wire system only first, third and fifth screen will be available.</p> |
| Press "I" | <p>The first screen : Displays phase current of three phase and neutral current.</p> <p>The second screen : Displays phase maximum current demand of three phase and average current .</p> <p>The third screen : Displays total percentage harmonic of current of three phase and average phase current.</p> <p>The fourth screen : Press for 3 sec, Displays current correction indication page.</p> <p>Note : For 3 Ø 3 wire system only first, second and third screen will be available. Displays average current instead of neutral current.</p> |
| Press "VAF" | <p>The first screen : Displays voltage, current, power factor of first phase and frequency.</p> <p>The second screen : Displays voltage, current, power factor of second phase and frequency.</p> <p>The third screen : Displays voltage, current, power factor of third phase and frequency.</p> <p>The fourth screen : Displays average value of voltage, current and power factor of three phase and frequency.</p> <p>Note : 1) In 3 Ø 3 wire system voltage current power factor and freq. will be line to line. 2) In 1 Ø 2 wire system only first screen will be available.</p> |
| Press "PF" | <p>The first screen : Displays power factor of three phase and average power factor.</p> <p>Note : For 3 Ø 3 wire system, only average power factor will be available on this screen.</p> |
| Press "P" | <p>The first screen : Displays active power of three phase and total active power.</p> <p>The second screen : Displays reactive power of three phase and total reactive power.</p> <p>The third screen : Displays apparent power of three phase and total apparent power.</p> <p>The fourth screen : Displays active, reactive, apparent power and power factor of first phase.</p> <p>The fifth screen : Displays active, reactive, apparent power and power factor of second phase.</p> <p>The sixth screen : Displays active, reactive, apparent power and power factor of third phase.</p> <p>The seventh screen : Displays total active, reactive, apparent power and average power factor of three phase.</p> <p>The eighth screen : Displays maximum active power demand, reactive power demand and apparent power demand.</p> <p>The ninth screen : Displays minimum active power demand and reactive power demand.</p> <p>Note : 1) For 3 Ø 3 wire system only seventh, eighth and ninth screen will be available. 2) In 1 Ø 2 wire system only first, second, third, fourth, eighth and ninth screen will be available.</p> |
| Press "E" | <p>The first screen : Displays active energy of three phase.</p> <p>The second screen : Displays apparent energy of three phase.</p> <p>The third screen : Displays reactive energy of three phase.</p> |

Note : For 1 phase 2 wire network, all page will be same as 3 phase 4 wire but only selected phase parameter will display.

AUTOMATIC / MANUAL MODE DESCRIPTION

Press E (←) button for 3 seconds to toggle between Automatic and Manual mode.
Note : By default unit operates in automatic mode. In automatic mode online pages scroll automatically at the rate of 5 seconds per page. In automatic mode when any key is pressed, unit temporarily switches to manual mode and the appropriate page is displayed, also if any key is not pressed for 5 sec, unit resumes automatic mode.

SERIAL NUMBER DESCRIPTION

Press PF (▲) key for 10sec. to display 8 digit serial number only for 10sec. at 5th line of display

CONFIGURATION

There are 6 dedicated keys with symbols marked as ◀, ▶, ▲, ▼, ↵, ↶. use these 6 keys to enter into configuration menu / change setting.
Note : The settings should be done by a professional, after going through this users manual and after having understood the application situation. For the configuration setting mode :

- Use ▲ + ▼ keys for 3 sec. to enter or exit from the configuration menu.
- Use ◀ or ▶ keys to move cursor left or right by one digit each time.
- Use ▲ or ▼ keys for increasing or decreasing parameters value.
- Use ↵ key to go back to previous page.
- Use ↶ key to save the setting and move on to next page.

| Config. page | Function | Range or Selection | Factory Setting |
|--------------|--------------------------|--|-----------------|
| | Password | 0000 to 9998 | 1000 |
| 1 | Change Password | No / Yes | No |
| 1.1 | New Password | 0000 to 9998 | 1000 |
| 2 | Network Selection | 3P4W, 3P3W, 1P2W-P1, 1P2W-P2 and 1P2W-P3 | 3P4W |
| 3 | CT Secondary | 1A or 5A | 5 |
| 4 | CT Primary | 1A, 5A to 10,000A | 5 |
| 5 | PT Secondary | 100V to 500V | 350 |
| 6 | PT primary | 100V to 500kV | 350 |
| 7 | Slave Id | 1 to 255 | 1 |
| 8 | Baud Rate | 300, 600, 1200, 2400, 4800, 9600 and 19200 (bps) | 9600 |
| 9 | Parity | None, Odd, Even | None |
| 10 | Stop Bit | 1 or 2 | 1 |
| 11 | Back Light | 0 to 7200 sec. | 0000 |
| 12 | Demand interval method | Sliding / Fixed | Sliding |
| 13 | Demand interval duration | 1 to 30 | 15 |
| 14 | Demand interval length | 1 to 30 min | 1 |

| Config page. | Function | Range or Selection | Factory Setting |
|--------------|-----------------------------|--------------------|-----------------|
| 15 | Max Page Auto | 1 to 21 | 21 |
| 16 | Change Page Sequence | No / Yes | No |
| 16.01 | Page sequence 1 | 1 to 21 | 1 |
| 16.02 | Page sequence 2 | 1 to 21 | 2 |
| 16.03 | Page sequence 3 | 1 to 21 | 3 |
| 16.04 | Page sequence 4 | 1 to 21 | 4 |
| 16.05 | Page sequence 5 | 1 to 21 | 5 |
| 16.06 | Page sequence 6 | 1 to 21 | 6 |
| 16.07 | Page sequence 7 | 1 to 21 | 7 |
| 16.08 | Page sequence 8 | 1 to 21 | 8 |
| 16.09 | Page sequence 9 | 1 to 21 | 9 |
| 16.10 | Page sequence 10 | 1 to 21 | 10 |
| 16.11 | Page sequence 11 | 1 to 21 | 11 |
| 16.12 | Page sequence 12 | 1 to 21 | 12 |
| 16.13 | Page sequence 13 | 1 to 21 | 13 |
| 16.14 | Page sequence 14 | 1 to 21 | 14 |
| 16.15 | Page sequence 15 | 1 to 21 | 15 |
| 16.16 | Page sequence 16 | 1 to 21 | 16 |
| 16.17 | Page sequence 17 | 1 to 21 | 17 |
| 16.18 | Page sequence 18 | 1 to 21 | 18 |
| 16.19 | Page sequence 19 | 1 to 21 | 19 |
| 16.20 | Page sequence 20 | 1 to 21 | 20 |
| 16.21 | Page sequence 21 | 1 to 21 | 21 |
| 17 | Pulse weight (kWh) | 0.01 to 99.99 | 0.01 |
| 18 | Pulse duration (Sec) | 0.1 to 2.0 | 0.1 |
| 19 | Factory default | No / Yes | No |
| 20 | Reset energy and MAX demand | No / Yes | No |
| 20.1 | Password | 0001 to 9999 | 1001 |
| 20.01 | Reset active energy | No / Yes | No |
| 20.02 | Reset reactive energy | No / Yes | No |
| 20.03 | Reset apparent energy | No / Yes | No |
| 20.04 | Reset MAX current | No / Yes | No |
| 20.05 | Reset MAX active power | No / Yes | No |
| 20.06 | Reset MIN active power | No / Yes | No |
| 20.07 | Reset MAX Reactive power | No / Yes | No |
| 20.08 | Reset MIN Reactive power | No / Yes | No |
| 20.09 | Reset MAX apparent power | No / Yes | No |

- For resetting energy parameters user will be prompted the password. If correct password is entered, the user will be able to reset all energy parameters. This password will be value which will be greater than the configuration password by 1.


NETWORK SELECTION AND WIRING INPUT

| Network selection in configuration mode | Wiring |
|---|-----------------------------|
| 3P4W | 3P4W, 2P3W, 1P2W (P1/P2/P3) |
| 3P3W | 3P3W |

Note : P1, P2 and P3 are Three Phase.


APPLICATION OF PULSE OUTPUT

● PROCESS INTEGRATION



Pulse output from MFM384 meter can be interfaced into a process through a PLC for on line control of energy content in the process. If the PLC has a self excited digital input, external DC supply is not needed. The kWh pulse is also used to derive average kWh information at the PLC.

● ENERGY CONTROLLER



Pulse output from MFM384 meter can be used as alarm generator or total energy controller by interfacing it with Pre-settable counter and control circuits (Contactors, Relay, Trip Circuit).

The counter is loaded with the maximum energy consumption. When count reaches setpoint it provides output to control circuit to take appropriate action.

Note : + and - is applicable only for 24V product

All fuse types : 0.5A class CC UL type
0.5A fast acting 600V

MODBUS REGISTER ADDRESSES LIST

Readable parameters for Communication Model Only : [Length (Register) : 2 ; Data Structure : Float]

| Address | Hex Address | Parameter |
|---------|-------------|--------------------|
| 30000 | 0x00 | Voltage V1N |
| 30002 | 0x02 | Voltage V2N |
| 30004 | 0x04 | Voltage V3N |
| 30006 | 0x06 | Average Voltage LN |
| 30008 | 0x08 | Voltage V12 |
| 30010 | 0x0A | Voltage V23 |
| 30012 | 0x0C | Voltage V31 |
| 30014 | 0x0E | Average Voltage LL |
| 30016 | 0x10 | Current I1 |
| 30018 | 0x12 | Current I2 |
| 30020 | 0x14 | Current I3 |
| 30022 | 0x16 | Average Current |
| 30024 | 0x18 | kW1 |
| 30026 | 0x1A | kW2 |
| 30028 | 0x1C | kW3 |
| 30030 | 0x1E | kVA1 |
| 30032 | 0x20 | kVA2 |
| 30034 | 0x22 | kVA3 |
| 30036 | 0x24 | kVAr1 |
| 30038 | 0x26 | kVAr2 |
| 30040 | 0x28 | kVAr3 |
| 30042 | 0x2A | Total kW |
| 30044 | 0x2C | Total kVA |
| 30046 | 0x2E | Total kVAr |
| 30048 | 0x30 | PF1 |
| 30050 | 0x32 | PF2 |
| 30052 | 0x34 | PF3 |
| 30054 | 0x36 | Average PF |
| 30056 | 0x38 | Frequency |
| 30058 | 0x3A | kWh |
| 30060 | 0x3C | kVAh |
| 30062 | 0x3E | kVArh |

Formula to find address of individual Harmonic

| Constant Parameter | Meaning |
|--------------------|-------------|
| 0 | Voltage V1N |
| 1 | Voltage V2N |
| 2 | Voltage V3N |
| 3 | Voltage V12 |
| 4 | Voltage V23 |
| 5 | Voltage V31 |
| 6 | Current I1 |
| 7 | Current I2 |
| 8 | Current I3 |

| Address | Hex Address | Parameter |
|---------|-------------|--|
| 30064 | 0x40 | kW MAX Active Power |
| 30066 | 0x42 | kW MIN Active Power |
| 30068 | 0x44 | kVAr MAX Reactive Power |
| 30070 | 0x46 | kVAr MIN Reactive Power |
| 30072 | 0x48 | kVA MAX Apparent Power |
| 30122 | 0x7A | Neutral Current |
| | | Total Harmonic Distortion (THD) |
| 30124 | 0x7C | THD of Voltage V1N |
| 30126 | 0x7E | THD of Voltage V2N |
| 30128 | 0x80 | THD of Voltage V3N |
| 30130 | 0x82 | THD of Voltage V12 |
| 30132 | 0x84 | THD of Voltage V23 |
| 30134 | 0x86 | THD of Voltage V31 |
| 30136 | 0x88 | THD of Current I1 |
| 30138 | 0x8A | THD of Current I2 |
| 30140 | 0x8C | THD of Current I3 |
| 30684 | 0x2AC | Serial number of unit |
| 30692 | 0x2B4 | MAX I1 Demand |
| 30694 | 0x2B6 | MAX I2 Demand |
| 30696 | 0x2B8 | MAX I3 Demand |
| 30698 | 0x2BA | MAX Avg. I Demand |
| 30700 | 0x2BC | Phase Sequence Indication (0-OK clockwise, 1-Anticlockwise, 2-Invalid) |
| 30702 | 0x2BE | Existing KW MAX Active Power |
| 30704 | 0x2C0 | Existing KW MIN Active Power |
| 30706 | 0x2C2 | Existing KVAr MAX Reactive Power |
| 30708 | 0x2C4 | Existing KVAr MIN Reactive Power |
| 30710 | 0x2C6 | Existing KVA MAX Apparent Power |
| 30712 | 0x2C8 | Existing MAX I1 Demand |
| 30714 | 0x2CA | Existing MAX I2 Demand |
| 30716 | 0x2CC | Existing MAX I3 Demand |
| 30718 | 0x2CE | Existing MAX Avg. I Demand |

{143 + [(Harmonic no-2) x 2] + 60 x Constant Parameter }

For Example,

To find the 14th Harmonic address of Voltage V31 following formula can be used :

Formula with the parameter :
 {143 + [(Harmonic no-2) x 2] + 60 x C P}
 Eg. {143 + [(14-2) x 2] + 60 x 5} = 467

So, Check the 14th Harmonic of Voltage V31 at 467 address.

Readable / writable parameters for Communication Model Only :

| Address | Hex Address | Parameter | Range | | Length (Register) | Data Structure |
|---------|-------------|---------------|-----------|-----------|-------------------|----------------|
| | | | Min value | Max value | | |
| 40000 | 0x00 | Password | 0 | 9998 | 1 | Integer |
| | | | Value | Meaning | | |
| 40001 | 0x01 | N/W selection | 0 | 3P-4W | 1 | Integer |
| | | | 1 | 3P-3W | 1 | Integer |
| | | | 2 | 1P2W-P1 | 1 | Integer |
| | | | 3 | 1P2W-P2 | 1 | Integer |
| | | | 4 | 1P2W-P3 | 1 | Integer |

MODBUS register addresses list *continued*

Readable / writable parameters for Communication Model Only :

| Address | Hex Address | Parameter | Range | | Length (Register) | Data Structure |
|---------|-------------|-----------------------------------|---------------|------------------------------|-------------------|----------------|
| | | | Min value | Max value | | |
| 40002 | 0x02 | CT Secondary (A) | 1 | 5 | 1 | Integer |
| 40003 | 0x03 | CT primary (CT Secondary = 5) (A) | 5 | 10000 | 1 | Integer |
| | | CT primary (CT Secondary = 1) (A) | 1 | 10000 | | |
| 40004 | 0x04 | PT Secondary (V) | 100 | 500 | 1 | Integer |
| 40005 | 0x05 | PT primary (V) | 100 | 500000 | 2 | Integer |
| 40007 | 0x07 | Slave id | 1 | 255 | 1 | Integer |
| | | | Value | Meaning | | |
| 40008 | 0x08 | Baud rate (bps) | 0x0000 | 300 | 1 | Integer |
| | | | 0x0001 | 600 | | |
| | | | 0x0002 | 1200 | | |
| | | | 0x0003 | 2400 | | |
| | | | 0x0004 | 4800 | | |
| | | | 0x0005 | 9600 | | |
| | | | 0x0006 | 19200 | | |
| | | | Value | Meaning | | |
| 40009 | 0x09 | Parity | 0x0000 | None | 1 | Integer |
| | | | 0x0001 | Odd | | |
| | | | 0x0002 | Even | | |
| 40010 | 0x0A | Stop bit | 0x0000 | 1 | 1 | Integer |
| | | | 0x0001 | 2 | | |
| 40011 | 0x0B | Backlight OFF (sec.) | 0 | 7200 | 1 | Integer |
| 40012 | 0x0C | Factory Default | 1 | Set to factory setting range | 1 | Integer |
| 40013 | 0x0D | Reset kWh | 1 | Reset Total Active Energy | 1 | Integer |
| 40014 | 0x0E | Reset kVAh | 1 | Reset Total Apparent Energy | 1 | Integer |
| 40015 | 0x0F | Reset kVArh | 1 | Reset Total Reactive Energy | 1 | Integer |
| | | | Min value | Max value | | |
| 40016 | 0x10 | Auto Mode Pages | 1 | 21 | 1 | Integer |
| | | | Page No | Meaning | | |
| 40017 | 0x11 | Page Address Sequence | 1- 21 | 1- First Page ; 21-Last Page | 1 | Integer |
| 40018 | 0x12 | Page Address Sequence | 1- 21 | 1- First Page ; 21-Last Page | 1 | Integer |
| 40019 | 0x13 | Page Address Sequence | 1- 21 | 1- First Page ; 21-Last Page | 1 | Integer |
| 40020 | 0x14 | Page Address Sequence | 1- 21 | 1- First Page ; 21-Last Page | 1 | Integer |
| 40021 | 0x15 | Page Address Sequence | 1- 21 | 1- First Page ; 21-Last Page | 1 | Integer |
| 40022 | 0x16 | Page Address Sequence | 1- 21 | 1- First Page ; 21-Last Page | 1 | Integer |
| 40023 | 0x17 | Page Address Sequence | 1- 21 | 1- First Page ; 21-Last Page | 1 | Integer |
| 40024 | 0x18 | Page Address Sequence | 1- 21 | 1- First Page ; 21-Last Page | 1 | Integer |
| 40025 | 0x19 | Page Address Sequence | 1- 21 | 1- First Page ; 21-Last Page | 1 | Integer |
| 40026 | 0x1A | Page Address Sequence | 1- 21 | 1- First Page ; 21-Last Page | 1 | Integer |
| 40027 | 0x1B | Page Address Sequence | 1- 21 | 1- First Page ; 21-Last Page | 1 | Integer |
| 40028 | 0x1C | Page Address Sequence | 1- 21 | 1- First Page ; 21-Last Page | 1 | Integer |
| 40029 | 0x1D | Page Address Sequence | 1- 21 | 1- First Page ; 21-Last Page | 1 | Integer |
| 40030 | 0x1E | Page Address Sequence | 1- 21 | 1- First Page ; 21-Last Page | 1 | Integer |
| 40031 | 0x1F | Page Address Sequence | 1- 21 | 1- First Page ; 21-Last Page | 1 | Integer |
| 40032 | 0x20 | Page Address Sequence | 1- 21 | 1- First Page ; 21-Last Page | 1 | Integer |
| 40033 | 0x21 | Page Address Sequence | 1- 21 | 1- First Page ; 21-Last Page | 1 | Integer |
| | | | Value | Meaning | | |
| 40034 | 0x22 | Demand Interval Method | 0X0000 | Sliding | 1 | Integer |
| | | | 0X0001 | Fixed | | |
| 40035 | 0x23 | Demand Interval Duration | Min Value : 1 | Max Value : 30 | 1 | Integer |
| 40036 | 0x24 | Demand Interval Length(min) | Min Value : 1 | Max Value : 30 | 1 | Integer |
| 40037 | 0x25 | Reset MAX kW | 1 | Reset MAX Active power | 1 | Integer |
| 40038 | 0x26 | Reset MIN kW | 1 | Reset MIN Active power | 1 | Integer |

MODBUS REGISTER ADDRESSES LIST


MODBUS register addresses list *continued*

Readable / writable parameters Communication Model Only :


| Address | Hex Address | Parameter | Range | Length (Register) | Data Structure |
|---------|-------------|-----------------------|-------|------------------------------|----------------|
| 40039 | 0x27 | Reset MAX kVAr | 1 | Reset MAX Reactive power | 1 Integer |
| 40040 | 0x28 | Reset MIN kVAr | 1 | Reset MIN Reactive power | 1 Integer |
| 40041 | 0x29 | Reset MAX kVA | 1 | Reset MAX Apparent power | 1 Integer |
| 40054 | 0x36 | Page address Sequence | 1-21 | 1- First Page ; 21-Last Page | 1 Integer |
| 40055 | 0x37 | Page address Sequence | 1-21 | 1- First Page ; 21-Last Page | 1 Integer |
| 40057 | 0x39 | Pulse duration (Sec) | 0.1 | 2 | 1 Integer |
| 40058 | 0x3A | Pulse Weight (kWh) | 0.01 | 99.99 | 1 Integer |
| 40059 | 0x3B | Page address Sequence | 1-21 | 1- First Page ; 21-Last Page | 1 Integer |
| 40060 | 0x3C | Page address Sequence | 1-21 | 1- First Page ; 21-Last Page | 1 Integer |
| 40064 | 0x40 | Reset MAX Current | 1 | Reset MAX Current | 1 Integer |

TYPICAL WIRING DIAGRAM


3 PHASE 4-WIRE (COMMONLY USED)




3 PHASE 3-WIRE




3 Ø - 4 WIRE, 3 CT'S and 3 PT'S




3 Ø - 3 WIRE, 2 CT'S and 2 PT'S




2 PHASE - 3 WIRE



1 PHASE - 2 WIRE




2 Ø - 3 WIRE, 2 CT'S and 2 PT'S



All fuse types : 0.5A class CC UL type
0.5A fast acting 600V

CONNECTION DIAGRAM FOR COMMUNICATION



Contact sales for PC based monitoring software to communicate with the meters.

(Specifications subject to change as development is a continuous process.)

Selec Controls Pvt. Ltd., India

Factory Address :
EL-27/1, Electronic Zone, TTC Industrial Area,
MIDC, Mahape, Navi Mumbai - 400 710, INDIA.
Tel. No. : +91-22-28476443 / 1882
Fax No. : +91-22-28471733 | Toll free : 1800 227 353
Website: www.selec.com | Email: sales@selec.com