

MA12 / MA202 / MA302 / MA12-2 / MA302-2

OP331-V01

Programming Scheme

- MA202/MA302/MA302-2 : via rear key(Tact Switch)
- MA12/MA12-2 : via bottom key(Tact Switch)

Sr. No.	Function	Method	Display Indication
1	To enter programming mode.	Press switch for 5 sec	Ctr : For MA12 / MA202 / MA302
			Prg : For MA12-2 / MA302-2
2	CT Primary/ Shunt Selection	With every press of the key	5, 10, 20, 30, 40, 50, 60, 75, 80, 100, 150, 200, 250, 300, 400, 500, 600, 800, 1000, 1200, 1500, 1600, 2000, 2500, 3000, 4000.
3	To exit programming mode	Auto exit : 100sec or switch OFF the unit & then switch it ON.	—